

# Installation Brief for Nextep supplied NVA

## NVA: SPA-3000 (Analogue Telephone Adaptor)

### Please read all instructions carefully

1. Switch off your modem/router.
2. Connect an Ethernet Cable from your modem/router to the RJ45 port on the left side of the SPA3000 (as indicated in the picture below).
3. Connect the power lead to the 5V DC power connection on the left side of the SPA3000 (as indicated in the picture below). Connect the power plug to a power point.
4. Connect an analogue telephone handset to the RJ11 port marked "Phone" on the right side of the SPA3000 (as indicated in the picture below).



**Do not connect the "Phone" port of the SPA3000 into your telephone wall socket or you will cause the ATA to malfunction.**

5. Connect the enclosed telephone cable to the RJ11 port marked "Line" on the right hand side of the SPA3000 (as indicated in the picture below).
6. Connect the other end of the telephone cable to the telephone socket. **Please note:** if the phone number is being used for DSL then you will need to use a DSL filter, just like any other telephone device on a DSL line.
7. Restart all devices.
8. When the Internet connection is re-established, the SPA3000 should obtain an IP address and automatically download a configuration file from the NexVoice Provisioning Server. After 30 seconds the configuration should be complete. The telephone connected to the SPA3000 should have a dial tone and you will be able to make telephone calls.



RJ-45  
10BaseT  
Ethernet port

LED  
Link Activity

5 Volt  
Power  
Connection



Phone Line

LED  
Unit status

If you require any further assistance, please call Nextep Broadband Customer Support Help Desk on **1800 639 837**.